




Ultra Slim Case with Built-in Battery Designed for iPhone 4 and 4S

User Manual


WELCOME

Thank you for purchasing the iContact case with built-in rechargeable battery for iPhone 4 and 4S. When used properly, this battery case can double the time you use your iPhone before you have to stop to plug it in again. When your phone's internal battery is almost empty, simply switch to the auxiliary battery built into the case and keep using your phone without interruption.

CONTENTS



USING THE CASE



CHARGING

Backup battery can be charged with the included Micro-USB cable, with original Apple USB charger, or USB ports of your Mac or PC. When charging backup battery, the LED lights will flash from left to right.

When iPhone is inserted in the case and connected to a power source, the iPhone will be charged first (about 3 hours), then the backup battery.

Press the button on the backup battery for 2 seconds to run or stop charge for iPhone.

BATTERY CONSUMPTION

When iPhone and backup battery are connected to a power source, the power for the iPhone comes from the power source. If the power source is disconnected, the power for the iPhone comes first from the backup battery (until the backup battery is less than 5%), then from the iPhone's internal battery.

LED LIGHT INDICATION

Press the button to indicate the backup battery's actual power level.

4 LED Lights: 80% - 100% power

3 LED Lights: 60% - 80% power

2 LED Lights: 40% - 60% power

1 LED Lights: 20% - 40% power

1 LED Flickers: Less than 20% power

SYNC

When the backup battery is charging your iPhone, you can synchronize your iPhone with iTunes without removing the backup battery.

ON / OFF

Press button for 2 seconds to turn the backup battery on or off.

QUALITY / SAFETY CONTROL

We choose grade "A" cells, protective ICs made in Japan or Taiwan, and other high quality raw materials. We conduct up to 16 tests at each stage of assembly, including parts, work-in-progress and final product. Any defective parts are rejected. A protective circuit will prevent the backup battery from short-circuiting, over-charging and over-discharging even under extreme conditions.

MAINTENANCE

Follow these guidelines to keep your battery operating to its fullest potential:

1. Recharge the battery once every three months when it is not in use.
2. Keep the battery dry and away from moist and corrosive materials.
3. Do not wash the battery with harsh chemicals, soaps or detergents.

WARNING!

Read all included instructions and warnings prior to using this product. Failure to read and follow safety instructions could result in fire, explosion, electrical shock or other hazard causing serious and/or fatal injury and/or property damage.

1. Do not modify, disassemble, open, drop, crush, puncture or shred this product.
2. Do not expose the product to rain, water or other liquids.
3. Keep away from open flame and sunlight to prevent heat build-up.
4. Keep away from high voltage devices.
5. This product is not a toy. Keep away from children. Ensure that all persons who use the product read and follow these warnings and instructions.

Exercise caution when using this product and use at your own risk. We shall not be held liable for any damages resulting from the use of this product.

SPECIFICATIONS

CELL TYPE:	Rechargeable Li-polymer	Audio Play:	Up to 35 hours
CAPACITY:	1500mAh	Video Play:	Up to 7 hours
INPUT:	5V/500mA	SIZE:	127x 62 x 15.6 mm
OUTPUT:	5V/500mA	WEIGHT:	55g
CYCLE LIFE:	500 Times (full charges)	COMPATIBILITY:	iPhone4 / iPhone 4S
STAND BY:	Up to 210 hours		
TALK TIME:	Up to 4.5 hours on 3G network Up to 9 hours on 2G network		
INTERNET:	Up to 4.5 hours on 3G network Up to 7 hours on Wi-Fi		



www.iContactProducts.com